

/boot/config.txt

[pi4]

Used to fix kvmd-otg and kvmd-tc358743 not starting at boot

```
dtoverlay=tc358743  
dtoverlay=disable-bt  
dtoverlay=dwc2,dr_mode=peripheral
```

Revision #4

Created 2024-01-24 11:31:39 UTC

Updated 2026-01-12 06:36:06 UTC by etorres