

PiKVM

Important Lines for /boot/config.txt

Used to fix kvmd-otg and kvmd-tc358743 not starting at boot

```
dtoverlay=tc358743  
dtoverlay=disable-bt  
dtoverlay=dwc2,dr_mode=peripheral
```

Revision #2

Created 24 January 2024 11:31:39

Updated 5 November 2024 15:58:58